

Not to scale

00-057BL – Sash Lift Handle (black)

For 424 and 748 Systems



Pack of 2 handles per window sash

00-057SC – Sash Lift Handle (satin chrome)

For 424 and 748 Systems



Pack of 2 handles per window sash

00-058 – Latch (Double Hung)



00-058-92607 – Latch (Double Hung)




00-060 – Keeper (Double Hung)

For 424 and 748 Systems



00-535 – Screen Catch



02-014 – 3mm Woolpile



02-015 – 4mm Woolpile



02-019 – Fin Seal 48 T Slot 4.25mm



02-040 – 4mm Q-Lon



Up to date stock availability can be viewed at www.lidco.com.au/indices

DESIGNER RANGE 424 SYSTEM

Thermaview™ Double Hung Window

Not to scale

02-082 – Bulb Seal (PVC)



02-153 – V Seal (Mullion)

Suitable for COM-020, COM-041,
700-646, 400-314



03-059 – Alignment Spring

For 424 and 748 Systems



03-134 – Sash Stop (Bottom)



03-135 – Sash Stop (Top)



04-065 – 6mm Glazing Channel



04-067 – 5mm Glazing Channel



04-209 – 10mm Glazing Channel



04-333 – 18mm Glazing Channel



04-545 – 4mm Glazing Channel




Up to date stock availability can be viewed at www.lidco.com.au/indices

Not to scale


05-504 – Gasket (65mm D/Hung Head)

For 424 System



05-505 – Gasket (65mm D/Hung Sill)

For 424 System




05-555 – Corner Stake




05-673 – Corner Stake

Suitable for 400-673



06-136 – Balance Tube Screw



06-672 – Friction Foot (424/748)




09-266 – Offset Clip (Stainless Steel)



09-271 – Turn Button Long (Black)



09-278 – Flexible Handle (black)



09-537 – Screen Clip (Double Hung)



Up to date stock availability can be viewed at www.lidco.com.au/indices

DESIGNER RANGE 424 SYSTEM


Thermaview™ Double Hung Window



Date: Aug 2013
Replaces: Jul 2013

Not to scale

09-538 – Head Clip (Double Hung)



Up to date stock availability can be viewed at www.lidco.com.au/indices


SALES ORDERS orders@lidco.com.au F 1300 937 713

TECHNICAL SUPPORT techsupport@lidco.com.au T 1300 663 848

Spiral Balance Guide

Spiral Balance Selection Table		
Part Number	Body Length	Weight
06-500-01	318	2.25 – 7.25kg
06-500-02	343	2.25 – 7.25kg
06-500-03	368	2.25 – 7.25kg
06-500-04	394	2.25 – 7.25kg
06-500-05	419	2.25 – 7.25kg
06-500-06	445	2.25 – 7.25kg
06-500-07	470	2.25 – 7.25kg
06-500-08	495	2.25 – 7.25kg
06-500-09	521	2.25 – 7.25kg
06-500-10	546	2.25 – 7.25kg
06-500-11	572	2.25 – 7.25kg
06-500-12	597	2.25 – 7.25kg
06-500-13	622	2.25 – 7.25kg
06-500-14	648	7.25kg – 10kg
06-500-15	673	7.25kg – 10kg
06-500-16	699	7.25kg – 10kg
06-500-17	724	7.25kg – 10kg
06-500-18	749	7.25kg – 10kg
06-500-19	775	7.25kg – 10kg
06-500-20	800	7.25kg – 10kg
06-500-21	826	7.25kg – 10kg
06-500-22	851	7.25kg – 10kg
06-500-23	876	10kg – 14kg
06-500-24	902	10kg – 14kg
06-500-25	927	10kg – 14kg
06-500-26	953	10kg – 14kg
06-500-27	978	10kg – 14kg
06-500-28	1003	10kg – 14kg
06-500-29	1029	10kg – 14kg

Suitable for Lidco double hung windows




Up to date stock availability can be viewed at www.lidco.com.au/indices

Spring Balance Selection Guide

Each double hung window requires **FOUR** Spring Feet and **ONE** Spring Balance Kit.

Spring Balance Kit includes:

- 4 x Springs
- 4 x Tubes
- 4 x Stops
- 4 x End Caps



Spring Balance Selection Chart – 4mm Glass

		Double Hung Window Frame Width (mm)									
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	799	06-600-015	06-600-016	06-600-016	06-600-016	06-600-016	06-600-017	06-600-017	06-600-017	06-600-017	06-600-018
	899	06-600-022	06-600-023	06-600-023	06-600-023	06-600-024	06-600-024	06-600-024	06-600-024	06-600-025	06-600-025
	999	06-600-030	06-600-030	06-600-030	06-600-031	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032
	1099	06-600-037	06-600-037	06-600-038	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039
	1199	06-600-044	06-600-044	06-600-045	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046
	1299	06-600-051	06-600-052	06-600-052	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053
	1399	06-600-058	06-600-059	06-600-059	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061
	1499	06-600-066	06-600-066	06-600-067	06-600-067	06-600-067	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068
	1599	06-600-073	06-600-073	06-600-074	06-600-074	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075
	1699	06-600-080	06-600-080	06-600-081	06-600-081	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-082
	1799	06-600-087	06-600-088	06-600-088	06-600-088	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-089
	1899	06-600-094	06-600-095	06-600-095	06-600-095	06-600-095	06-600-096	06-600-096	06-600-096	06-600-096	06-600-097
	1999	06-600-102	06-600-102	06-600-102	06-600-102	06-600-103	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104
	2099	06-600-109	06-600-109	06-600-109	06-600-109	06-600-110	06-600-110	06-600-110	06-600-110	06-600-111	06-600-111
	2199	06-600-116	06-600-116	06-600-116	06-600-116	06-600-117	06-600-117	06-600-117	06-600-118	06-600-118	06-600-118
2299	06-600-123	06-600-123	06-600-123	06-600-124	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-125	

Up to date stock availability can be viewed at www.lidco.com.au/indices

Spring Balance Selection Guide

Spring Balance Selection Chart – 5mm Glass											
Double Hung Window Frame Width (mm)											
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	799	06-600-016	06-600-016	06-600-016	06-600-017	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018
	899	06-600-023	06-600-023	06-600-024	06-600-024	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025
	999	06-600-030	06-600-031	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032
	1099	06-600-037	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040
	1199	06-600-045	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047
	1299	06-600-052	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054
	1399	06-600-059	06-600-060	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061	06-600-061	06-600-061	06-600-061
	1499	06-600-066	06-600-067	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068	06-600-068	06-600-068	06-600-069
	1599	06-600-074	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075	06-600-075	06-600-076	06-600-076
	1699	06-600-081	06-600-081	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083
	1799	06-600-088	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-089	06-600-090	06-600-090	06-600-090
	1899	06-600-095	06-600-095	06-600-095	06-600-096	06-600-096	06-600-096	06-600-097	06-600-097	06-600-097	06-600-097
	1999	06-600-102	06-600-102	06-600-103	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104	06-600-104	06-600-105
	2099	06-600-109	06-600-109	06-600-110	06-600-110	06-600-110	06-600-111	06-600-111	06-600-111	06-600-112	06-600-112
	2199	06-600-116	06-600-116	06-600-117	06-600-117	06-600-117	06-600-118	06-600-118	06-600-118	06-600-119	06-600-119
2299	06-600-123	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-125	06-600-126	06-600-126	06-600-126	

Spring Balance Selection Chart – 6mm Glass											
Double Hung Window Frame Width (mm)											
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	799	06-600-016	06-600-016	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018
	899	06-600-023	06-600-024	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-026
	999	06-600-031	06-600-031	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-032	06-600-033	06-600-033
	1099	06-600-038	06-600-038	06-600-039	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040
	1199	06-600-045	06-600-046	06-600-046	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047	06-600-047	06-600-047
	1299	06-600-052	06-600-053	06-600-053	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054	06-600-054	06-600-055
	1399	06-600-060	06-600-060	06-600-060	06-600-060	06-600-061	06-600-061	06-600-061	06-600-061	06-600-062	06-600-062
	1499	06-600-067	06-600-067	06-600-067	06-600-068	06-600-068	06-600-068	06-600-068	06-600-069	06-600-069	06-600-069
	1599	06-600-074	06-600-074	06-600-074	06-600-075	06-600-075	06-600-075	06-600-076	06-600-076	06-600-076	06-600-077
	1699	06-600-081	06-600-081	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083	06-600-083	06-600-083	06-600-084
	1799	06-600-088	06-600-088	06-600-089	06-600-089	06-600-089	06-600-090	06-600-090	06-600-090	06-600-091	06-600-091
	1899	06-600-095	06-600-096	06-600-096	06-600-096	06-600-097	06-600-097	06-600-097	06-600-098	06-600-098	06-600-098
	1999	06-600-102	06-600-103	06-600-103	06-600-103	06-600-104	06-600-104	06-600-105	06-600-105	06-600-105	-
	2099	06-600-109	06-600-110	06-600-110	06-600-111	06-600-111	06-600-111	06-600-112	06-600-112	06-600-112	-
	2199	06-600-116	06-600-117	06-600-117	06-600-118	06-600-118	06-600-119	06-600-119	06-600-119	-	-
2299	06-600-124	06-600-124	06-600-124	06-600-125	06-600-125	06-600-126	06-600-126	06-600-126	-	-	

Up to date stock availability can be viewed at www.lidco.com.au/indices

Spring Balance Selection Guide

Spring Balance Selection Chart – 8mm Glass											
Double Hung Window Frame Width (mm)											
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	799	06-600-017	06-600-017	06-600-018	06-600-018	06-600-018	06-600-018	06-600-018	06-600-019	06-600-019	06-600-019
	899	06-600-024	06-600-025	06-600-025	06-600-025	06-600-025	06-600-025	06-600-026	06-600-026	06-600-026	06-600-026
	999	06-600-032	06-600-032	06-600-032	06-600-032	06-600-033	06-600-033	06-600-033	06-600-033	06-600-034	06-600-034
	1099	06-600-039	06-600-039	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040	06-600-041	06-600-041	06-600-041
	1199	06-600-046	06-600-046	06-600-046	06-600-047	06-600-047	06-600-047	06-600-048	06-600-048	06-600-048	06-600-049
	1299	06-600-053	06-600-053	06-600-054	06-600-054	06-600-054	06-600-055	06-600-055	06-600-055	06-600-056	06-600-056
	1399	06-600-060	06-600-060	06-600-061	06-600-061	06-600-062	06-600-062	06-600-062	06-600-063	06-600-063	06-600-063
	1499	06-600-067	06-600-068	06-600-068	06-600-068	06-600-069	06-600-069	06-600-070	06-600-070	06-600-070	-
	1599	06-600-074	06-600-075	06-600-075	06-600-076	06-600-076	06-600-076	06-600-077	06-600-077	06-600-077	-
	1699	06-600-082	06-600-082	06-600-082	06-600-083	06-600-083	06-600-084	06-600-084	06-600-084	-	-
	1799	06-600-089	06-600-089	06-600-090	06-600-090	06-600-091	06-600-091	06-600-091	-	-	-
	1899	06-600-096	06-600-096	06-600-097	06-600-097	06-600-098	06-600-098	-	-	-	-
	1999	06-600-103	06-600-104	06-600-104	06-600-105	06-600-105	06-600-105	-	-	-	-
	2099	06-600-110	06-600-111	06-600-111	06-600-112	06-600-112	-	-	-	-	-
	2199	06-600-117	06-600-118	06-600-118	06-600-119	06-600-119	-	-	-	-	-
2299	06-600-124	06-600-125	06-600-126	06-600-126	-	-	-	-	-	-	

Spring Balance Selection Chart – 10mm Glass											
Double Hung Window Frame Width (mm)											
		600	700	800	900	1000	1100	1200	1300	1400	1500
Double Hung Window Frame Height (mm)	799	06-600-018	06-600-018	06-600-018	06-600-018	06-600-019	06-600-019	06-600-019	06-600-019	06-600-020	06-600-020
	899	06-600-025	06-600-025	06-600-025	06-600-026	06-600-026	06-600-026	06-600-026	06-600-027	06-600-027	06-600-027
	999	06-600-032	06-600-032	06-600-033	06-600-033	06-600-033	06-600-033	06-600-034	06-600-034	06-600-034	06-600-035
	1099	06-600-039	06-600-039	06-600-040	06-600-040	06-600-040	06-600-041	06-600-041	06-600-041	06-600-042	06-600-042
	1199	06-600-046	06-600-047	06-600-047	06-600-047	06-600-048	06-600-048	06-600-049	06-600-049	06-600-049	-
	1299	06-600-053	06-600-054	06-600-054	06-600-055	06-600-055	06-600-055	06-600-056	06-600-056	-	-
	1399	06-600-061	06-600-061	06-600-062	06-600-062	06-600-062	06-600-063	06-600-063	-	-	-
	1499	06-600-068	06-600-068	06-600-069	06-600-069	06-600-070	06-600-070	-	-	-	-
	1599	06-600-075	06-600-076	06-600-076	06-600-077	06-600-077	06-600-077	-	-	-	-
	1699	06-600-082	06-600-083	06-600-083	06-600-084	06-600-084	-	-	-	-	-
	1799	06-600-089	06-600-090	06-600-091	06-600-091	-	-	-	-	-	-
	1899	06-600-097	06-600-097	06-600-098	06-600-098	-	-	-	-	-	-
	1999	06-600-104	06-600-104	06-600-105	-	-	-	-	-	-	-
	2099	06-600-111	06-600-112	06-600-112	-	-	-	-	-	-	-
	2199	06-600-118	06-600-119	06-600-119	-	-	-	-	-	-	-
2299	06-600-125	06-600-126	-	-	-	-	-	-	-	-	

Up to date stock availability can be viewed at www.lidco.com.au/indices